



RV-PNDT

INSTALLATION SHEET

Bracket Installation

Fixings required to mount the Pendant bracket will depend upon the fixing surface. It is important to use adequate quality fixings to safely support the complete dome assembly. Fixing slots on 4" PCD provide adequate clearance for 6mm bolts.

Flying Lead Installation

Install the flying lead optionally through the central mounting tube or via the 20mm gland entry point. Note the gland entry is supplied with a 20 x 1.5 mm thread to accommodate industry standard 20mm glands.

Attaching The Dome

Lift cosmetic ABS cover to expose mounting fixture. Unscrew dome hand locknut fully clockwise. Offer dome to bracket with flat on mounting bracket aligned to the rear. Note it is important to ensure that the 2 lugs on the mounting support are fully engaged with the corresponding grooves on the dome mounting plate (See figure 1).

Once engaged secure the dome by tightening hand locknut anti clockwise.

Contents

- Swan neck assembly
- 4 metre flying lead



Figure 1