



RV-VISOR INSTALLATION SHEET

Preparation

Dome must be properly supported before Visor fitting. Fixing the Camera to an RV-PED and securing the base is recommended. Visor should be attached at low level prior to installation.

Attaching the Visor

Securing tabs locate behind the casting rib as shown FIG B. Align the 2 fixing holes on the visor with the threaded holes on the Ball Top. Assemble the visor to the Camera using the fixings/spacers provided. Assembly stack comprises, from the outside Cap Head Screw, Nylon Washer, Visor, Nylon Washer, Spacer, Nyltite. Securing with Allen key as shown FIG B.

Contents

- Visor
- 2 off M4 x 20 Socket Cap Screws
- 4 off M4 Nylon Washers
- 2 off M4 Nyltites
- 2 off M4 Spacers
- 1 off M3 Allen Key
- 1 off Bird Spike
- 1 off 3 x 8 Pan Head Pozi s/s
- 2 off 3mm Crinkle Washer s/s



NOTE: Visors cannot be retrofitted to all Redvision X-Series Cameras. Confirmation of visor option can be confirmed by e-mailing camera serial number to Redvision for inspection.